

Welcome to the KOR-FX Setup section!

The best way to set up your KOR-FX Vest is to watch our setup videos. We also offer a Setup.pdf with operational instructions. If you have questions, please use the Support section of our forums or email info@korfx.com.

DONGLE

Power Button

- To turn the dongle on, slide the Power Button to the “on” position.
- If the green indicator LED is solid, then the dongle is connected to the Vest.
- If the green indicator LED is blinking slowly, then either:
 - a) the Vest is not turned on,
 - b) the Vest is not bound to the dongle, or
 - c) the Vest is out of range.

Bind Key

- Press and hold the Bind Key for 1.5 seconds to enter “bind” mode. The LED will flash.
- Pressing again will exit bind mode.
- While the dongle’s LED is blinking, and making sure the KOR-FX Vest is turned on, press the Bind key on the KOR-FX Vest for up to 10 seconds or until the dongle’s LED turns solid green. The Vest is now bound to the dongle.
- If you go out of the dongle’s range or have issues with your computer’s Wi-Fi connection, re-binding the Vest to the dongle should resolve any problems.

Volume Wheel

- The Volume Wheel will adjust the volume to your headphones / speakers.
- NOTE: For the best effects, the audio source you are connecting to the dongle should always be set to maximum volume. After the dongle and Vest are set up and in use, do not use your system’s audio controls. Instead, you must use the dongle’s Volume Wheel to control the volume of your media in your headphones / speakers.

Intensity Control Wheel

- The Intensity Control Wheel will control how much of the “effect” is being output to the Vest. It is very important to adjust this to your desired setting while using the Vest.
- Changing the intensity can significantly enhance your experience and we recommend getting familiar with the different levels of intensity and how they react with your media.

“Line IN”

- This is the 3.5 mm audio input source from your TV, tablet, console, phone, PC, or laptop.

- If you are using a device with adjustable audio output (such as a laptop or PC), make sure the audio is set to “high” in the media player / game and system. The dongle needs full power audio to maximize its effects.

“Line OUT”

- This is the 3.5 mm audio output to your headphones or speakers.

KOR-FX VEST

Up Key

- Press and release the Up key to increase vibration amplitude. The speaker will output “up” until the maximum level is reached, and then it will output a tone.
- Press and hold the Up key for 2 seconds to enter Left /Right balance adjustment mode. The speaker will output two continuous tones.
- In Left / Right balance adjustment mode, pressing and releasing the Up key will increase R-Channel vibration 2% at the same time it decreases L-Channel vibration 2%. The speaker will output a tone. If you reach the maximum adjustment (10% increase for R and 10% decrease for L) the speaker will output another tone.
- In Left /Right balance adjustment mode, pressing and holding the Up key for 2 seconds will exit that mode. The speaker will output two continuous tones.
- Note that Left / Right adjustment is not needed unless you feel that effects are unevenly balanced.

Down Key

- Press and release the Down key to decrease vibration amplitude. The speaker will output “down” until the lowest level is reached, and then it will output a tone.
- In Left / Right balance adjustment mode, pressing and releasing the Down key will decrease R-Channel vibration 2% at the same time it increases L-Channel vibration 2%. The speaker will output a tone. If you reach the maximum adjustment (10% decrease for R and 10% increase for L) the speaker will output another tone.
- Note that Left / Right adjustment is not needed unless you feel that effects are unevenly balanced.

Mode Key

- Press and release the Mode key to change the filter. The speaker will output “Filter 1”, “Filter 2,” or “Filter 3.”
 - a) Filter 1 = Low Frequency
 - b) Filter 2 = Mid-Range Frequency (recommended for most situations)
 - c) Filter 3 = Mid and High Range Frequency
- TEST TONE MODE: Pressing and holding the Mode key for 2 seconds will output left and rights vibrations so you can adjust the vest and find the best placement on your body. Press the Mode key again to exit Test Tone Mode.

Power Key

- Press and hold the Power key for 2 seconds to power on the unit. The speaker will output "On."
- Press and hold the Power key for 2 seconds to power off the unit. The speaker will output "Off."
- Press and release the Power key to enable / disable channel enhancement. The speaker will output "Effect on", "tone", "tone", "tone", or "Effect off." This will shut off the frequency filters.

Bind Key (Please see above section "Dongle – Bind Key" to learn how to bind the Vest to the dongle))